Ghost printer settings

The right paper setting for every Ghost transfer material

MATERIAL	 **Little Ghost** PRINTER DRIVER PostScript 3 driver	 **Big Ghost** PRINTER DRIVER HP Universal Printing PS	 **Ghost Pro X Essential** RIP SOFTWARE iColor ProRIP Essentials	 **Ghost Pro X** RIP SOFTWARE Digital Factory OKI Edition
A-Foil / Flex Soft	**Normal 2 / Normal H**	**Not specified**	**Presto! 2 Step Textile**	**A-Foil Ghost Laser Dark**
Multitrans	**Coated 1** Multi-purpose tray	**High gloss / very heavy**	**Presto Hard Surface**	**A Multitrans Ghost**
Multitrans Pro	**Coated 3** Multi-purpose tray	**Transparent foil**	**Presto Wood Paper**	**A Multitrans Ghost / Ultra Heavy 2**
Decal	**Coated 3** Multi-purpose tray	**High gloss / very heavy**	**Clear PET Label / Aqua Clear**	–
Tattoo Paper	**Heavy 2** Multi-purpose tray	**Labels**	**Easy Tattoo**	**A-Foil Ghost Tattoo Paper**
Outdoor Foil	**Coated 3** Multi-purpose tray	**Labels**	**Clear PET Label**	–

– = no setting specified, as not compatible · On the Little Ghost, feed the material via the multi-purpose tray (where stated).

Important: The matching paper setting applies to all Ghost papers and foils. Incorrect or unsuitable settings can damage your printer. Such damage is self-inflicted and not covered by any warranty or guarantee. If in doubt, please contact us before printing.